

| Corrigendum of Signal Location Book 2024-25 |          |                      |
|---------------------------------------------|----------|----------------------|
| UPDATED 06.04.2025                          |          |                      |
| ITARSI - AMLA (ET-AMLA)                     |          |                      |
| Signal/Station                              | Location | Position             |
| Saheli (SAHL)                               | 771.78   | Left                 |
| Gate                                        | 772/16   | Removed              |
| Gate Distant                                | 773/12   | Removed              |
| Gate Inner Distant                          | 774/16   | Removed              |
| Gate (232)                                  | 775/14   | Removed              |
| Kala Akhar (KQE)                            | 778.05   | Right                |
| Distant                                     | 775/02   | Left                 |
| Inner Distant                               | 776/02   | Left                 |
| Pola Pathar (POX)                           | 784.26   | Left                 |
| Distant                                     | 781/30   | Left                 |
| Inner Distant                               | 783/02   | Left                 |
| Gate (SW-2)                                 | 783/02   | Removed              |
| Gate (237- A)                               | 793/42   | Removed              |
| Gate (240)                                  | 798/06   | Removed              |
| Dharakhoh (DHQ)                             | 830.45   | Right                |
| PSR 834/22-836/36                           | 50 Kmph  | M/Exp.               |
| PSR 834/22-836/36                           | 55 Kmph  | Goods                |
| PSR 839/8-842/30                            | 50 Kmph  | M/Exp.               |
| PSR 839/8-842/30                            | 60 Kmph  | Goods                |
| Maramjhiri (MJY)                            | 843.2    | Left                 |
| AMLA - ITARSI (AMLA - ET)                   |          |                      |
| Maramjhiri (MJY)                            | 843.2    | Right                |
| Home (S-20)                                 | 844/21   | Right                |
| PSR For Gds. Loaded Train                   | 60 Kmph  |                      |
| PSR for Empty Gds. Train                    | 75 Kmph  |                      |
| PSR 842/49-840/37                           | 70 Kmph  |                      |
| PSR 840/37-839/11                           | 65 Kmph  | 4 <sup>0</sup> Curve |
| PSR 837/47-837/13                           | 65 Kmph  | 4 <sup>0</sup> Curve |
| PSR 835/01-834/27                           | 65 Kmph  | 4 <sup>0</sup> Curve |
| PSR 842/31-842/41                           | 50 Kmph  | Removed              |
| Gate                                        | 783/15   | Removed              |
| Dharakhoh (DHQ)                             | 830.45   | Left                 |
| Repeater Home                               | 831/33   | Right                |
| Kala Akhar (KQE)                            | 778.05   | Left                 |
| Distant                                     | 780/21   | Left                 |
| Inner Distant                               | 779/23   | Left                 |
| Home (S-19)                                 | 778/31   | Left                 |
| Starter (S-13)                              | 775/25   | Left                 |
| Adv.Starter (S-12)                          | 777/07   | Left                 |

|                                                    |                 |                 |
|----------------------------------------------------|-----------------|-----------------|
| <b>TAKU (TAKU)</b>                                 | <b>767.57</b>   | <b>Left</b>     |
| Inner Distant                                      | 769/19-17       | Left            |
| <b>Corrigendum of Signal Location Book 2024-25</b> |                 |                 |
| <b>BALHARSHAH - NAGPUR (BPQ-NGP)</b>               |                 |                 |
| <b>Signal/Station</b>                              | <b>Location</b> | <b>Position</b> |
| <b>Ballarshah (BPQ)</b>                            | <b>890.43</b>   | <b>Right</b>    |
| IBS (S-17)                                         | 885/31-29       | Left            |
| <b>Babupeth (BUPH)</b>                             | <b>881.45</b>   | <b>Right</b>    |
| <b>Tadali (TAE)</b>                                | <b>869.09</b>   | <b>Right</b>    |
| <b>Bhandak (BUX)</b>                               | <b>852.17</b>   | <b>Right</b>    |
| Adv. Starter                                       | 851/23-19       | Left            |
| <b>Seloo Road (SLOR)</b>                           | <b>772.06</b>   | <b>Left</b>     |
| Distant                                            | 769/28-30       | Left            |
| Inner Distant                                      | 770/12-14       | Left            |
| Home (S-2)                                         | 771/14-16       | Left            |
| L/Line Starter (S-7)                               | 772/16-18       | Left            |
| M/Line Starter (S-8)                               | 772/18-20       | Left            |
| Intermediate Starter (S-23)                        | 773/12-14       | Left            |
| Adv. Starter (S-24)                                | 773/24-26       | Left            |
| <b>Sindi (SNI)</b>                                 | <b>790.00</b>   | <b>Right</b>    |
| Distant                                            | 785/24-28       | Left            |
| Inner Distant                                      | 786/26-28       | Left            |
| Home (S-1)                                         | 787/22-24       | Left            |
| Routing Home (S-2)                                 | 788/18-20       | Left            |
| <b>NAGPUR-BALHARSHAH (NGP-BPQ)</b>                 |                 |                 |
| <b>Signal/Station</b>                              | <b>Location</b> | <b>Position</b> |
| <b>Borkhedi (BOK)</b>                              | <b>801.43</b>   | <b>Right</b>    |
| Inner Distant                                      | 803/07-05       | Left            |
| <b>Sindi (SNI)</b>                                 | <b>790.00</b>   | <b>Left</b>     |
| Starter (S-26)                                     | 789/07-03       | Left            |
| Intermediate Starter (S-22)                        | 788/11-09       | Left            |
| Adv. Starter (S-57)                                | 787/27-25       | Left            |
| <b>Seloo Road (SLOR)</b>                           | <b>772.06</b>   | <b>Right</b>    |
| Distant                                            | 776/03-01       | Left            |
| Inner Distant                                      | 775/03-05       | Left            |
| Home (S-32)                                        | 773/27-25       | Left            |
| Inner Home (S-37)                                  | 772/21-19       | Left            |
| L/Line Starter (S-45)                              | 771/29-27       | Left            |
| M/Line Starter (S-46)                              | 771/29-27       | Left            |
| Adv. Starter (S-51)                                | 771/17-15       | Left            |
| <b>Bhandak (BUX)</b>                               | <b>852.17</b>   | <b>Left</b>     |
| Inner Distant                                      | 850/18-20       | Left            |
| Home (S/CO-01)                                     | 851/20-22       | Left            |
| L/Line Starter (S-4)                               | 852/28-30       | Left            |

|                                                    |                  |                 |
|----------------------------------------------------|------------------|-----------------|
| M/Line Starter (S-3)                               | 852/29-30        | Left            |
| Adv. Starter (S-8)                                 | 853/08-10        | Left            |
| <b>Corrigendum of Signal Location Book 2024-25</b> |                  |                 |
| <b>Signal/Station</b>                              | <b>Location</b>  | <b>Position</b> |
| <b>Tadali (TAE)</b>                                | <b>861.9</b>     | <b>Left</b>     |
| Distant                                            | 858/02-04        | Left            |
| Inner Distant                                      | 859/04-06        | Left            |
| Home (S-32)                                        | 860/10-12        | Left            |
| <b>3rd LINE CKNI - SEWAGRAM (CKNI-SEGM)</b>        |                  |                 |
| <b>Chikni Road (CKNI)</b>                          | <b>820.07</b>    | <b>Right</b>    |
| Adv. Starter (S-23)                                | 819/18-16        | Left            |
| <b>Nagri (NGI)</b>                                 | <b>807.94</b>    | <b>Left</b>     |
| Disant                                             | 810/30-28        | Left            |
| Inner Distant                                      | 810/02-809/36    | Left            |
| Home (S/Co-48)                                     | 808//34-32       | Left            |
| UP & DN L/Line Starter (S-41)                      | 807/26-24        | Left            |
| M/Line Starter (S/42)                              | 807/24-22        | Left            |
| UP & DN L/Line Starter-1 (S-43)                    | 807/22-20        | Left            |
| Inner Distant                                      | 805/28A-26A      | Left            |
| Gate -19                                           | 804/18A-16A      | Left            |
| <b>Hinganghat (HGT)</b>                            | <b>791.42</b>    | <b>Left</b>     |
| M/Line Starter                                     | 790/36B-32A      | Left            |
| L/Line Starter                                     | 790/34a-32a      | Left            |
| M/Line Intermediate Starter                        | HGT2016A         | Left            |
| L/Line Intermediate Starter                        | HGT2016A         | Left            |
| <b>3rd LINE SEWAGRAM - CKNI (SEGM-CKNI)</b>        |                  |                 |
| <b>Yenor (YNA)</b>                                 | <b>797.09</b>    | <b>Left</b>     |
| Distant                                            | 802/6A-8A        | Left            |
| Inner Distant                                      | 803/6A-8A        | Left            |
| Gate (19)                                          | 805/26A-28A      | Left            |
| <b>Nagri (NGI)</b>                                 | <b>807.94</b>    | <b>Left</b>     |
| Home                                               | 806/30A-32A      | Left            |
| UP & DN L/Line Starter-2 (S-23)                    | NGI/2020A        | Left            |
| M/Line Starter (S-24)                              | NGI/2014-808/10A | Left            |
| UP & DN L/Line Starter-1 (S-25)                    | NGI/2014-808/10A | Left            |
| <b>Chikni Road (CKNI)</b>                          | <b>820.07</b>    | <b>Left</b>     |
| Distant                                            | 816/28-817/02    | Left            |
| Inner Distant                                      | 817/28-818/02    | Left            |
| Home (S/Co-01)                                     | 819/04-06        | Left            |
| <b>MAJRI - ADILABAD (MJRI-ADB)</b>                 |                  |                 |
| <b>Wani (WANI)</b>                                 | <b>855.07</b>    | <b>Left</b>     |
| M/L Starter & WCL Starter                          | 856/01           | Right           |
| L/Line Starter & Pass. L/Line Starter              | 856/01           | Left            |
| <b>Majri Khadan (MJKN)</b>                         | <b>845.62</b>    | <b>Right</b>    |

|                                                                    |                 |                 |
|--------------------------------------------------------------------|-----------------|-----------------|
| Siding Starter                                                     | 845r/26-28      | Left            |
| <b>Note- In page 67: Item - 6, 7, 8, 13 &amp; 22 to be deleted</b> |                 |                 |
| <b>Corrigendum of Signal Location Book 2024-25</b>                 |                 |                 |
| <b>Signal/Station</b>                                              | <b>Location</b> | <b>Position</b> |
| <b>ADILABAD - MAJRI (ADB-MJRI)</b>                                 |                 |                 |
| <b>Pimpalkhui (PMKT)</b>                                           | <b>922.04</b>   | <b>Left</b>     |
| M/Line Starter                                                     | 921/06          | Left            |
| Adv.Starter                                                        | 921/02          | Left            |
| <b>Majri Khadan (MJKN)</b>                                         | <b>845.62</b>   | <b>Left</b>     |
| Siding Starter                                                     | 845R/18-16      | Left            |
| L/Line-1 Starter                                                   | 845R/18-16      | Left            |
| L/Line-2 Starter                                                   | 845R/16-14      | Left            |
| <b>CHHINDWADA - AMLA (CWA-AMLA)</b>                                |                 |                 |
| <b>Signal/Station</b>                                              | <b>Location</b> | <b>Position</b> |
| <b>Chhindwara (CWA)</b>                                            | <b>989.85</b>   | <b>Left</b>     |
| Gate PC-21                                                         | 988/18          | Left            |
| <b>Khirsadoh (KUX) D-Class</b>                                     | <b>968.76</b>   | <b>Left</b>     |
| Engine Stop Board                                                  | 963/20          | Left            |
| <b>Hirdagarh (HRG)</b>                                             | <b>932.29</b>   | <b>Right</b>    |
| Warning Board (Goods)                                              | 935/07          | Left            |
| <b>Bordhai (BXY)</b>                                               | <b>901.77</b>   | <b>Left</b>     |
| M/Line Starter (S-19)                                              | 901/11          | Left            |
| <b>Jambara (JMV)</b>                                               | <b>888.45</b>   | <b>Right</b>    |
| Adv. Starter (S-15)                                                | 887/13          | Left            |
| <b>Amla (AMLA)</b>                                                 | <b>874.68</b>   | <b>Left</b>     |
| Starter for PF-5 (S-64)                                            | 887/13          | Left            |
| <b>AMLA - CHHINDWADA (AMLA - CWA)</b>                              |                 |                 |
| <b>Amla (AMLA)</b>                                                 | <b>874.68</b>   | <b>Right</b>    |
| Starter for PF-6 (S-13)                                            | AMF1082         | Left            |
| <b>Barelipar (BQM) D-Class</b>                                     | <b>894.15</b>   | <b>Left</b>     |
| PH Board                                                           | 910/06          | Left            |
| <b>Markadhana (MKDN) D-Class</b>                                   | <b>926.26</b>   | <b>Right</b>    |
| PH Engine Stop Board                                               | 926/05          | Left            |
| <b>Hirdagarh (HRG)</b>                                             | <b>932.29</b>   | <b>Left</b>     |
| M/Line Starter (S-8)                                               | 932/11          | Left            |
| <b>Parasia (PUX)</b>                                               | <b>961.28</b>   | <b>Right</b>    |
| Routing Home (S-5)                                                 | 960/16          | Left            |
| <b>CHHINDWARA - NAINPUR (CWA-NIR) (UP)</b>                         |                 |                 |
| <b>Signal/Station</b>                                              | <b>Location</b> | <b>Position</b> |
| <b>Chhindwara (CWA)</b>                                            | <b>1257.62</b>  | <b>Left</b>     |
| Starter PF-1 S-14 & PF-2 S-16                                      | 1257/6          | Left            |
| Starter PF-5 S-28                                                  | CWA-2048        | Left            |
| Starter PF-6 S-26                                                  | CWA-3048        | Left            |

|                                    |                    |              |
|------------------------------------|--------------------|--------------|
| Advance Starter S-48               | 1256/09C           | Left         |
| PSR 1255/21C to 1255/8C            | • 90 •             |              |
| PSR 1254/18C to 1253/15C           | • 105 •            |              |
| <b>DJ Open Board</b>               | <b>1253/2C</b>     | <b>N/S</b>   |
| PSR 1251/17C to 1251/1C            | • 75 •             |              |
| PSR 1248/12C to 1245/2C            | • 100 •            |              |
| <b>Ghat Parasia (GPSA) D-Class</b> | <b>1246.97</b>     | <b>Right</b> |
| PH Board                           | 1247/11C           | Left         |
| Engine Stop Board                  | 1246/12C           | Left         |
| <b>Umaria (ULH) D-Class</b>        | <b>1243.30</b>     | <b>Right</b> |
| PH Board                           | 1243/12C           | Left         |
| Engine Stop Board                  | 1243/01C           | Left         |
| PSR 1242/17C to 1241/13C           | • 90 •             |              |
| PSR 1241/10C-1241/9C               | • 50 •             |              |
| PSR 1241/8C to 1239/14C            | • 100 •            |              |
| <b>Jhilmilli (JLY)</b>             | <b>1238.19</b>     | <b>Right</b> |
| Warning Board                      | 1240/13C           | Left         |
| Distant                            | 1240/5C            | Left         |
| PSR 1239/5C to 1238/19C            | • 105 •            |              |
| <b>Home (S-1)</b>                  | <b>1239/3C</b>     | <b>Left</b>  |
| PSR 1238/15C to 1238/1C            | • 90 •             |              |
| Starter M/L S-3 & L/L S-5          | 1237/19C & 1237/20 | Left         |
| Advance Starter S-27               | 1237/14C           | Left         |
| PSR 1237/12C to 1237/4C            | • 100 •            |              |
| PSR 1235/23C to 1235/08C           | • 50 •             |              |
| <b>Markahandi (MOH) D-Class</b>    | <b>1233.43</b>     | <b>Left</b>  |
| PH Board                           | 1233/16C           | Left         |
| Engine Stop Board                  | 1233/4C            | Left         |
| PSR 1233/1C to 1232/7C             | • 90 •             |              |
| PSR 1231/20C to 1230/8C            | • 100 •            |              |
| 1229/17C to 1228/23C               | • 95 •             |              |
| PSR 1228/22C to 1226/17C           | • 75 •             |              |
| <b>Chourai (CHUA)</b>              | <b>1224.38</b>     | <b>Right</b> |
| Warning Board                      | 1227/9C            | Left         |
| Distant                            | 1226/13C           | Left         |
| PSR 1225/19C to 1225/6C            | • 105 •            |              |
| <b>Home (S-1)</b>                  | <b>1225/15C</b>    | <b>Left</b>  |
| Starter M/L S-3 & L/L S-5          | 1224/09C           | Left         |
| Advance Starter S-27               | 1224/03C           | Left         |
| <b>DJ Open Board</b>               | <b>1222/17C</b>    | <b>N/S</b>   |
| Kapurdah (KPDH) D-Class            | 1219.438           | Right        |
| PH Board                           | 1219/17C           | Left         |
| Engine Stop Board                  | 1219/3C            | Left         |
| <b>Samaswara (SMSR) D-Class</b>    | <b>1216.44</b>     | <b>Right</b> |

|                                    |                 |              |
|------------------------------------|-----------------|--------------|
| PH Board                           | 1217/3C         | Left         |
| Engine Stop Board                  | 1216/6C         | Left         |
| <b>Pipardahi (PED)</b>             | <b>1208.57</b>  | <b>Right</b> |
| Warning Board                      | 1211/2C         | Left         |
| PSR 1210/22C to 1210/6C            | • 90 •          |              |
| Distant                            | 1210/18C        | Left         |
| <b>Home (S-1)</b>                  | <b>1209/13C</b> | <b>Left</b>  |
| Starter M/L S-3 & L/L S-5          | 1208/09C        | Left         |
| Advance Starter S-27               | 1208/3C         | Left         |
| <b>Matradham (MADM) D-Class</b>    | <b>1204.11</b>  | <b>Right</b> |
| PH Board                           | 1204/12C        | Left         |
| Engine Stop Board                  | 1203/15C        | Left         |
| PSR 1197/26C to 1197/8C            | • 95 •          |              |
| <b>Seoni (SEY)</b>                 | <b>1192.59</b>  | <b>Right</b> |
| Gate Warning Board                 | 1195/3C         | Left         |
| Gate Distant                       | 1194/14C        | Left         |
| Gate (L/C-NC 50) S-GS 1            | 1193/17C        | Left         |
| <b>Home (S-1)</b>                  | <b>1193/13C</b> | <b>Left</b>  |
| PSR 1192/24C to 1192/20C           | • 95 •          |              |
| Repeater (For Starter) PF-1        | 1192/10C        | Right        |
| Repeater (For Starter) PF-2        | 1192/10C        | Left         |
| PSR 1192/9C to 1191/21C            | • 70 •          |              |
| Starter M/L S-3, L/L S-5 & L/L S-7 | 1191/23C        | Left         |
| PSR 1191/14C to 1191/5C            | • 75 •          |              |
| Advance Starter S-27               | 1191/12C        | Left         |
| Gate L/C-47 S-GS-3                 | 1190/20         | Left         |
| PSR 1190/8C to 1189/8C             | • 80 •          |              |
| Gate Warning Board                 | 1188/22C        | Left         |
| Gate Distant                       | 1188/15C        | Left         |
| PSR 1188/12C to 1187/20C           | • 75 •          |              |
| <b>DJ Open Board</b>               | <b>1187/17C</b> | <b>N/S</b>   |
| Gate L/C-44A S-GS-5                | 1187/12C        | Left         |
| PSR 1187/10C to 1186/15C           | • 90 •          |              |
| PSR 1186/07 to 1186/1C             | • 100 •         |              |
| PSR 1185/2C to 1184/06C            | • 95 •          |              |
| PSR 1182/20C to 1181/26C           | • 95 •          |              |
| PSR 1181/23C to 1181/2C            | • 70 •          |              |
| PSR 1180/16C to 1180/9C            | • 100 •         |              |
| PSR 1178/16C to 1178/6C            | • 80 •          |              |
| PSR 1177/7C to 1177/1C             | • 85 •          |              |
| PSR 1176/17 to 1176/1C             | • 80 • • 85 •   |              |
| <b>Bhoma (BHV)</b>                 | <b>1173.23</b>  | <b>Right</b> |
| Warning Board                      | 1175/17C        | Left         |
| PSR 1175/12C to 1175/3C            | • 80 •          |              |

|                                 |                 |              |
|---------------------------------|-----------------|--------------|
| Distant                         | 1175/10C        | Left         |
| PSR 1174/11C to 1174/4C         | • 105 •         |              |
| <b>Home (S-1)</b>               | <b>1174/10</b>  | <b>Left</b>  |
| Starter M/L S-3 & L/L S-5       | 1173/2C         | Left         |
| PSR 1173/9C to 1173/1C          | • 100 •         |              |
| Advance Starter S-27            | 1172/14C        | Left         |
| <b>DJ Open Board</b>            | <b>1170/8C</b>  | <b>N/S</b>   |
| PSR 1169/15C to 1169/5C         | • 105 •         |              |
| <b>Kanhiwara (KWB) D-Class</b>  | <b>1166.27</b>  | <b>Right</b> |
| PH Board                        | 1167/4C         | Left         |
| Engine Stop Board               | 1166/7C         | Left         |
| PSR 1166/2C to 1165/13C         | • 105 •         |              |
| PSR 1161/16C to 1161/11C        | • 105 •         |              |
| <b>Jurtara (JRTR) D-Class</b>   | <b>1161.44</b>  | <b>Right</b> |
| PH Board                        | 1162/2C         | Left         |
| Engine Stop Board               | 1161/5C         | Left         |
| <b>Palari (PUE)</b>             | <b>1153.54</b>  | <b>Right</b> |
| Warning Board                   | 1155/14C        | Left         |
| Distant                         | 1155/7C         | Left         |
| <b>Home (S-1)</b>               | <b>1154/4C</b>  | <b>Left</b>  |
| PSR 1153/11C to 1153/2C         | • 105 •         |              |
| Starter M/L S-3 & L/L S-5       | 1153/2C         | Left         |
| PSR 1152/21C to 1152/3C         | • 90 • • 85 •   |              |
| Advance Starter S-27            | 1152/19         | Left         |
| PSR 1151/7C to 1150/15C         | • 105 •         |              |
| <b>Khairee (KHR) D-Class</b>    | <b>1148.45</b>  | <b>Right</b> |
| PH Board                        | 1148/16C        | Left         |
| Engine Stop Board               | 1148/4C         | Left         |
| PSR 1146/12C to 1146/5C         | • 95 •          |              |
| <b>Keolari (KLZ)</b>            | <b>1140.94</b>  | <b>Right</b> |
| Warning Board                   | 1143/3C         | Left         |
| Distant                         | 1142/12C        | Left         |
| <b>Home (S-1)</b>               | <b>1141/14C</b> | <b>Left</b>  |
| Starter M/L S-3 & L/L S-5       | 1140/12C        | Left         |
| PSR 1140/8C to 1139/12C         | • 95 •          |              |
| Advance Starter S-27            | 1140/7C         | Left         |
| <b>Bothia (BOYA) D-Class</b>    | <b>1136.13</b>  | <b>Right</b> |
| PH Board                        | 1136/13C        | Left         |
| Engine Stop Board               | 1136/1C         | Left         |
| <b>DJ Open Board</b>            | <b>1135/5C</b>  | <b>N/S</b>   |
| PSR 1132/15C to 1132/1C         | • 105 •         |              |
| <b>Gangatola (GNGT) D-Class</b> | <b>1130.85</b>  | <b>Right</b> |
| PH Board                        | 1131/6          | Left         |
| Engine Stop Board               | 1130/10         | Left         |

|                                          |                 |                 |
|------------------------------------------|-----------------|-----------------|
| PSR 1130/1C to 1129/9C                   | • 90 •          |                 |
| PSR 1129/6C to 1128/12C                  | • 105 •         |                 |
| <b>Khairranji (KRRI) D-Class</b>         | <b>1124.74</b>  | <b>Right</b>    |
| PH Board                                 | 1125/5C         | Left            |
| Engine Stop Board                        | 1124/9C         | Left            |
| PSR 1121/21C to 1121/6C                  | • 95 •          |                 |
| PSR 1120/16 to 1119/7C                   | • 105 •         |                 |
| <b>Nainpur (NIR)</b>                     | <b>1118.97</b>  | <b>Left</b>     |
| Warning Board                            | 1120/6C         | Left            |
| Distant                                  | 1119/15C        | Left            |
| <b>Home (S-4)</b>                        | <b>1118/19C</b> | <b>Left</b>     |
| Starter PF-1 S-6 & PF-2 S-8              | 1118/3G         | Left            |
| Starter M/L PF-3 S-16                    | 1116/16         | Left            |
| Starter PF-4 S-18                        | 1116/17         | Left            |
| <b>NAINPUR CHHINDWARA (NIR-CWA) (DN)</b> |                 |                 |
| <b>Signal/Station</b>                    | <b>Location</b> | <b>Position</b> |
| <b>NAINPUR (NIR)</b>                     | <b>1118.96</b>  | <b>Right</b>    |
| L/L Starter PF-1 (S-7)                   | 1119/5          | Left            |
| L/L Starter PF-2 (S-5)                   | 1119/5          | Left            |
| M/L Starter PF-3 (S-11)                  | NIR2040         | Left            |
| L/L Starter PF-4 (S-13)                  | NIR2040         | Left            |
| Advance Starter (S-35)                   | 1118/14C        | Left            |
| PSR 1119/7C to 1120/16C                  | • 105 •         |                 |
| PSR 1121/6C to 1121/21C                  | • 95 •          |                 |
| <b>Khairranji (KRRI) D-Class</b>         | <b>1124.74</b>  | <b>Left</b>     |
| PH Board                                 | 1124/2C         | Left            |
| Engine Stop Board                        | 1124/13C        | Left            |
| PSR 1128/12C to 1129/6C                  | • 105 •         |                 |
| PSR 1129/7C to 1130/1C                   | • 95 •          |                 |
| <b>Gangatola(GNGT) D-Class</b>           | <b>1130.84</b>  | <b>Left</b>     |
| PH Board                                 | 1130/3C         | Left            |
| Engine Stop Board                        | 1130/15C        | Left            |
| PSR 1132/1C to 1132/15C                  | • 105 •         |                 |
| <b>DJ Open Board</b>                     | <b>1135/3C</b>  | <b>N/S</b>      |
| <b>Bothia (BOYA) D class</b>             | <b>1136.13</b>  | <b>Left</b>     |
| PH Board                                 | 1135/8C         | Left            |
| Engine Stop Board                        | 1136/6C         | Left            |
| <b>Keolari (KLZ)</b>                     | <b>1140.93</b>  | <b>Left</b>     |
| Warning Board                            | 1138/10C        | Left            |
| Distant                                  | 1139/1C         | Left            |
| PSR 1139/11C to 1140/8C                  | • 95 •          |                 |
| <b>Home (S-2)</b>                        | <b>1140/1C</b>  | <b>Left</b>     |
| Starter M/L S-4 & L/L S-6                | 1141/5C         | Left            |
| Advance Starter S-28                     | 1141/10C        | Left            |

|                                 |                 |             |
|---------------------------------|-----------------|-------------|
| PSR 1146/5C to 1146/12C         | • 95 •          |             |
| <b>Khairee (KHR) D-Class</b>    | <b>1148.45</b>  | <b>Left</b> |
| PH Board                        | 1147/11C        | Left        |
| Engine Stop Board               | 1148/9C         | Left        |
| PSR 1150/14c to 1151/7C         | • 105 •         |             |
| <b>Palari (PUE)</b>             | <b>1153.53</b>  | <b>Left</b> |
| Warning Board                   | 1150/15C        | Left        |
| Distant                         | 1151/9C         | Left        |
| PSR 1152/3C to 1152/12C         | • 85 •          |             |
| <b>Home (S-2)</b>               | <b>1152/12C</b> | <b>Left</b> |
| PSR 1152/15 to 1152/21C         | • 90 •          |             |
| PSR 1153/2C to 1153/11C         | • 105 •         |             |
| Starter M/L S-4 & L/L S-6       | 1153/16C        | Left        |
| Advance Starter (S-28)          | 1153/20C        | Left        |
| <b>Jurtara (JRTR) D-Class</b>   | <b>1161.44</b>  | <b>Left</b> |
| PH Board                        | 1160/11C        | Left        |
| Engine Stop Board               | 1161/10C        | Left        |
| PSR 1161/10C to 1161/16C        | • 105 •         |             |
| PSR 1165/13C to 1166/2C         | • 105 •         |             |
| <b>Kanhiwara (KWB) D-Class)</b> | <b>1166.27</b>  | <b>Left</b> |
| PH Board                        | 1165/13C        | Left        |
| Engine Stop Board               | 1166/12C        | Left        |
| PSR 1169/5C to 1169/15C         | • 105 •         |             |
| <b>DJ Open Board</b>            | <b>1170/6C</b>  | <b>N/S</b>  |
| <b>Bhoma(BHV)</b>               | <b>1173.23</b>  | <b>Left</b> |
| Warning Board                   | 1171/1C         | Left        |
| Distant                         | 1171/7C         | Left        |
| <b>Home (S-2)</b>               | <b>1172/9C</b>  | <b>Left</b> |
| PSR 1173/1C to 1173/9C          | • 100 •         |             |
| Starter M/L S-4 & L/L S-6       | 1173/19C        | Left        |
| PSR 1174/4C to 1174/11C         | • 105 •         |             |
| Advance Starter S-28            | 1174/5C         | Left        |
| PSR 1175/3C to 1175/12C         | • 80 •          |             |
| PSR 1176/17C to 1176/1C         | • 85 • • 80 •   |             |
| PSR 1177/1C to 1177/7C          | • 85 •          |             |
| PSR 1178/6C to 1178/16C         | • 80 •          |             |
| PSR 1180/9C to 1180/16C         | • 100 •         |             |
| PSR 1181/2C to 1181/23C         | • 70 •          |             |
| PSR 1181/26C to 1182/20C        | • 95 •          |             |
| PSR 1184/6C to 1185/2C          | • 95 •          |             |
| Gate Warning Board              | 1185/11C        | Left        |
| Gate Distant                    | 1186/1C         | Left        |
| PSR 1186/1C to 1186/7C          | • 100 •         |             |
| PSR 1186/15C to 1187/10C        | • 90 •          |             |

|                                  |                 |             |
|----------------------------------|-----------------|-------------|
| Gate Signal (GS-6)               | 1187/2C         | Left        |
| <b>DJ Open Board</b>             | <b>1187/16C</b> | <b>N/S</b>  |
| PSR 1187/20C to 1188/12C         | 75              |             |
| <b>Seoni (SEY)</b>               | <b>1192.58</b>  | <b>Left</b> |
| Gate Warning Board               | 1189/1C         | Left        |
| PSR 1189/8C to 1190/8C           | • 80 •          |             |
| Gate Distant                     | 1189/9C         | Left        |
| Gate Signal (GS-4)               | 1190/12C        | Left        |
| <b>Home (S-2)</b>                | <b>1191/4C</b>  | <b>Left</b> |
| PSR 1191/5C to 1911/14C          | • 75 •          |             |
| PSR 1192/21C to 1192/9C          | • 70 •          |             |
| PSR 1192/19C to 1192/24C         | • 105 •         |             |
| Starter M/L (PF-2) S-4 & L/L S-6 | 1192/19C        | Left        |
| Starter L/L (PF-1) S-8           | 1192/19C        | Left        |
| Advance Starter S-28             | 1193/6C         | Left        |
| PSR 1197/8C to 1197/26C          | • 95 •          |             |
| <b>Matradham (MADM) D-Class</b>  | <b>1204.1</b>   | <b>Left</b> |
| PH Board                         | 1203/6C         | Left        |
| Engine Stop Board                | 1204/5C         | Left        |
| <b>Pipardahi (PED)</b>           | <b>1208.56</b>  | <b>Left</b> |
| Warning Board                    | 1206/12C        | Left        |
| Distant                          | 1206/19C        | Left        |
| <b>Home (S-2)</b>                | <b>1207/14C</b> | <b>Left</b> |
| Starter M/L S-4 & L/L S-6        | 1209/3C         | Left        |
| Advance Starter S-28             | 1209/8C         | Left        |
| PSR 1210/6C to 1210/22C          | • 90 •          |             |
| <b>Samaswara (SMSR) D-Class</b>  | <b>1216.43</b>  | <b>Left</b> |
| PH Board                         | 1215/12C        | Left        |
| Engine Stop Board                | 1216/14C        | Left        |
| <b>Kapurdha (KPDH) D-Class</b>   | <b>1219.43</b>  | <b>Left</b> |
| PH Board                         | 1218/12C        | Left        |
| Engine Stop Board                | 1219/9C         | Left        |
| <b>Chourai (CHUA)</b>            | <b>1224.38</b>  | <b>Left</b> |
| Warning Board                    | 1222/2C         | Left        |
| Distant                          | 1222/8C         | Left        |
| <b>DJ Open Board</b>             | <b>122/15C</b>  | <b>N/S</b>  |
| <b>Home (S-2)</b>                | <b>1223/9C</b>  | <b>Left</b> |
| PSR 1225/6C to 1225/19C          | • 105 •         |             |
| Starter M/L S-4 & L/L S-6        | 1225/01C        | Left        |
| Advance Starter S-28             | 1226/8C         | Left        |
| PSR 1226/17C to 1228/22C         | • 75 •          |             |
| PSR 1228/23C to 1229/17C         | • 95 •          |             |
| PSR 1230/8C to 1231/20C          | • 100 •         |             |
| PSR 1232/7C to 1233/1C           | • 90 •          |             |

|                                    |                   |              |
|------------------------------------|-------------------|--------------|
| <b>Markahandi (MOH) D-Class</b>    | <b>1233.42</b>    | <b>Right</b> |
| PH Board                           | 1232/14C          | Left         |
| Engine Stop Board                  | 1233/8C           | Left         |
| PSR 1235/8C to 1235/23C            | • 50 •            |              |
| <b>Jhilmilli (JLY)</b>             | <b>1238.19</b>    | <b>Left</b>  |
| Warning Board                      | 1235/23C          | Left         |
| Distant                            | 1236/6C           | Left         |
| PSR 1237/4C to 1237/15C            | • 100 •           |              |
| <b>Home (S-2)</b>                  | <b>1237/8C</b>    | <b>Left</b>  |
| PSR 1238/1C to 1238/15C            | • 90 •            |              |
| Starter M/L S-4 & L/L S-6          | 1238/15C          | Left         |
| Advance Starter S-28               | 1238/20C          | Left         |
| PSR 1238/19C to 1239/5C            | • 105 •           |              |
| PSR 1239/14 to 1241/8C             | • 100 •           |              |
| PSR 1241/08C to 1241/10C           | • 50 •            |              |
| PSR 1242/03C to 1242/17C           | • 90 •            |              |
| <b>Umaria (ULH) D-Class</b>        | <b>1243.29</b>    | <b>Left</b>  |
| PH Board                           |                   |              |
| Engine Stop Board                  | 1243/6C           | Left         |
| <b>Ghat Parasia (GPSA) D-Class</b> | <b>1246.96</b>    | <b>Left</b>  |
| PSR 1245/2C to 1245/11C            | • 100 •           |              |
| PH Board                           | 1246/5C           | Left         |
| PSR 1246/14C to 1247/5C            | • 100 •           |              |
| Engine Stop Board                  | 1247/3C           | Left         |
| PSR 1247/13C to 1248/12C           | • 100 •           |              |
| PSR 1251/01 to 1251/17C            | • 75 •            |              |
| <b>DJ Open Board</b>               | <b>1252/16C</b>   | <b>N/S</b>   |
| PSR 1253/15C to 1254/18C           | • 105 •           |              |
| <b>Chhindwara (CWA)</b>            | <b>1257.61</b>    | <b>Right</b> |
| Warning Board                      | 1254/15           | Left         |
| Distant                            | 1255/2C           | Left         |
| PSR 1255/8C to 1255/21C            | • 90 •            |              |
| <b>Home (S-2)</b>                  | <b>1256/3C</b>    | <b>Left</b>  |
| Starter PF-1 S-5                   | 989/16            | Left         |
| Starter PF-2 S-7                   | CWA/1006B         | Left         |
| Starter PF-3 S-9 & PF-4 S-11       | CWA/1014          | Left         |
| Starter PF-5 S-27 & PF64 S-29      | CWA1029 & CWA1027 | Left         |